

Wireless Kinetic Energy Switch

Installation Instruction















No Wiring




Before first use please read instructions carefully.

Digital Instructions



https://tinyurl.com/smart-switch-install

Contents



^{*}The components detailed in this installation instruction are for reference only. Actual components may vary slightly.



Specifications and models

wireless kinetic energy switch technical parameters

Power supply: Micro energy acquisition and self generating(no battery)

Operating frequency: 433MHz


Control distance: 80m (outdoor), 30m (indoor)

Control method : pairing with wireless receiving controller

Quantity of keys: 1-2 keys Usage: 150000 times

IP rating: 65

Operating temperature: -20°C to 40°C



Test result: is from actual distance in laboratory.
This switch is for indoor lighting control use only.

The best way to use this switch is mount it on wall, we do not suggest using it remotely as it could cause the switch to be misplaced or dropped.

^{*} Warning: this switch has precision devices inside. Dropping of switch will likely cause damage.




Installation Methods

Two installation methods for wireless kinetic energy switch:

1 Adhesive installation method:

- 1-1 Applicable environment: glass, marble, ceramic tile and other smooth surface
- 1-2 Choose the installation position; clean the surface to ensure no oil/water etc. Ensure that it is dry.
- 1-3 Take the double sided adhesive tape, paste the tape on the bottom of switch in accordance with the mark on the bottom (See diagram 1-1A-01)




1-4 Paste the switch on surface; it will be fixed completely after few hours (See diagram 1-1A-02)



2 Plate installation


- 2-1 Applicable environment: flat wall such as gyprock wall
- 2-2 First remove the switch buttons from the switch block (refer to diagram 2-2A)



Care should be taken to ensure that switch block is orientated with the switches at the bottom of the switch block.

(refer to diagram 2-2B)

2-4 Replace switch buttons by pressing into place (refer to diagram 2-2C)







Pair with controller

The Lucesco Smart Switch needs to be paired with a Lucesco wireless controller. The ordinary pairing method is to press and hold the controller 'pairing key' button when the indicator light flashes and then press a button on the Smart Switch once (do not press continuosly).

The indicator light goes off, which means that the pairing is sucessful. Now the wirelesss controller can be controlled by this button.

For more detailed steps, please refer to the receiving controller instruction)

Directional pairing between two button switch and controller

To initiate directional pairing hold the "pairing key" on the controller for 3 seconds approx and release after LED indicator start flashing.

Then press one of the Smart Switch buttons four times (within 0.5 seconds), the indicator light goes off, which means pairing is successful.

After directional pairing is successful, the left button can only turn off and the right button can only turn on.

